

Euco Arbor Spacing Shims Metric

• Imperial Range also available

• **Ordering instructions** EUASS (Arbor Spacing Shim) and EUASC (Arbor Spacing Collar)



I.D	O.D	Thickness mm															
13	21	0.03	0.04	0.05	0.06		0.10	0.15	0.20	0.25	0.30	0.40	0.50	0.60	0.7	0.80	0.90
		1.00															
16	25	0.03	0.04	0.05	0.06	0.07	0.10	0.15	0.20	0.25	0.30	0.40	0.50	0.60	0.70	0.80	0.90
		1.00															
22	33	0.03	0.04	0.05	0.06	0.07	0.10	0.15	0.20	0.25	0.30	0.40	0.50	0.60	0.70	0.80	0.90
		1.00															
27	41	0.03	0.04	0.05	0.06	0.07	0.10	0.15	0.20	0.25	0.30	0.40	0.50	0.60	0.70	0.80	0.90
		1.00															
32	45	0.03	0.04	0.05	0.06		0.10	0.15	0.20	0.25	0.30	0.40	0.50	0.60	0.70	0.80	0.90
		1.00															
40	54	0.03	0.04	0.05	0.06	0.07	0.10	0.15	0.20	0.25	0.30	0.40	0.50	0.60	0.70	0.80	0.90
		1.00															
50	67	0.03	0.04	0.05	0.06		0.10	0.15	0.20	0.25	0.30	0.40	0.50	0.60	0.70	0.80	0.90
		1.00															
60	83			0.05	0.06		0.10	0.15	0.20	0.25	0.30	0.40	0.50	0.60	0.70	0.80	0.90
		1.00															
80	108						0.10	0.15	0.20	0.25	0.30	0.40	0.50	0.60	0.70	0.80	0.90
		1.00															

SPACING COLLARS

I.D	O.D	Widths															Standard Key-Way							
10	16	1	2	3	4	5	6	7	8	9	10	11	12	15	20	25	30							
13	22	1	2	3	4	5	6	7	8	9	10	11	12	15	20	25	30	40						
16	27	1	2	3	4	5	6	7	8	9	10	11	12	15	20	25	30	40	50	60				
22	34	1	2	3	4	5	6	7	8	9	10	11	12	15	20	25	30	40	50	60	70	80	90	100
27	39	1	2	3	4	5	6	7	8	9	10	11	12	15	20	25	30	40	50	60	70	80	90	100
32	45	1	2	3	4	5	6	7	8	9	10	11	12	15	20	25	30	40	50	60	70	80	90	100
40	55	1	2	3	4	5	6	7	8	9	10	11	12	15	20	25	30	40	50	60	70	80	90	100
50	65	1	2	3	4	5	6		8	9	10	11	12	15	20	25	30	40	50	60	70	80	90	100
60	84		2	3	4	5	6	7	8	9	10	11	12	15	20	25	30	40	50	60				100
80	109					5	6		8		10			15	20		30	40	50	60				100